

Manual, Assembly instruction: Brodit 804934

Left mount

1.)



2.)



3.)



4.)



Please read all instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the angled upper edge of the ProClip into the seam between the left speaker panel and the vintage number plate.
2. Pull/flex the lower part of the ProClip towards you so it hooks over the top of the vent opening.
3. The ProClip is in place
4. The ProClip is in place.