

## Manual, Assembly instruction: Brodit 804999

Left mount, High

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Pull out the rubber sealant on the A-post slightly. Remove the adhesive tape covers on the ProClip.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
3. Press the ProClip upward/forward so the angled upper edge hooks around the A-post.
4. The ProClip is in place.