

Manual, Assembly instruction: Brodit 805011

Left mount, Low

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Press the lip of the curved edge on top of the ProClip into the gap between the padded part of the dashboard and the air vent.
2. Flip the ProClip downward so the curved edge hooks underneath the small air vent.
3. Pull the ProClip slightly forward and at the same time hook the angled edge on the lower part of the ProClip around the edge of the air vent.
4. The ProClip is in place.