

Manual, Assembly instruction: Brodit 805078

Left mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Insert the enclosed gap opener into the gap below the frame surrounding the air vent, to widen the gap.

2. Insert the angled lower edge of the ProClip into the gap next to the gap opener. Note the cutouts.

3. Press the ProClip upward/forward so the angled lower edge goes all the way into the gap. Feel, and if necessary adjust the ProClip sideways, so the cutouts goes into position. Insert the angled upper edge of the ProClip into the gap above the frame surrounding the air vent. Remove the gap opener.

4. The ProClip is in place.