

Manual, Assembly instruction: Brodit 805090

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the cup holder and dashboard, to widen the gap.
2. Insert the lower s-shaped edge of the ProClip into the gap next to the gap opener.
3. Press the ProClip upward/forward so the lower edge goes all the way into the gap. Hook the angled upper edge of the ProClip around the edge on top of the dashboard. Remove the gap opener.
4. The ProClip is in place.