

Manual, Assembly instruction: Brodit 805095

Left mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap between the left side of the frame surrounding the air vent and the dash, to widen the gap. Remove the adhesive tape cover on the ProClip. Press the angled left edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

2. Press the gap opener into the right gap between the frame surrounding the air vent and the dash, to widen the gap. Press the angled right edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

3. The ProClip is in place.

4. The ProClip is in place.