

Manual, Assembly instruction: Brodit 805142

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the lower part of the ProClip into the gap between the rubber sealant and the A-post.
2. Press the ProClip upward/forward and hook the angled upper edge around the A-post.
3. Press downward on top of the ProClip so the angled edge hooks into place properly.
4. The ProClip is in place.