

Manual, Assembly instruction: Brodit 805214

Left mount ONLY for Comfort Dashboard WITHOUT a lid on the middle storage pocket.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the lower angled edge of the ProClip into the gap between the frame surrounding the air vent and the remainder of the dash.

2. Press the lower angled edge all the way into the gap.

3. Press the thin end of the enclosed gap opener into the upper gap between the frame surrounding the air vent and the remainder of the dash, to widen the gap. Insert the upper angled edge of the ProClip into the gap next to the gap opener. Remove the gap opener.

4. The ProClip is in place.