

Manual, Assembly instruction: Brodit 805240

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the upper angled edge of the ProClip into the seam between the inner vent and the frame surrounding the vent.
2. Press the lower edge of the ProClip upward and hook the lower edge over the outer silver vent frame.
3. The ProClip is in place.
4. The ProClip is in place.