

Manual, Assembly instruction: Brodit 805256

Left mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly.

2. Press the angled edge on the lower part of the ProClip into the gap.

3. Press the ProClip forward so the angled upper edge hooks into the gap between the windshield and the A-post. Press down on top of the ProClip so the adhesive tape attaches.

4. The ProClip is in place.