

Manual, Assembly instruction: Brodit 805276

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Insert the angled left edge of the ProClip under the rubber sealant on the A-post.
2. Press the right part of the holder forward and hook the angled right edge around the A-post.
3. Press the right part of the holder so the angled edge hooks properly around the A-post.
4. The ProClip is in place.