

Manual, Assembly instruction: Brodit 805283

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the angled lower edge of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

2. Press the thin end of the enclosed gap opener between the frame surrounding the air vent and the dashboard, to widen the gap. Hook the angled upper edge of the ProClip into the gap next to the gap opener.

3. Press the upper part of the ProClip downward so the angled edge goes all the way into the gap. Remove the gap opener.

4. The ProClip is in place.