

Manual, Assembly instruction: Brodit 805284

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Place the angled edge on the left part of the ProClip into the upper part of the air vent on the A-post.
2. Press the ProClip upward/forward so the angled edge on the left part hooks into the air vent and the right part hooks around the A-post.
3. Press forward/downward on top of the right part of the ProClip so the angled edge hooks properly around the A-post.
4. The ProClip is in place.