

Manual, Assembly instruction: Brodit 805291

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the rounded edge on the left part of the ProClip around the A-post.
2. Press the right part of the ProClip upward/forward so the angled edge hooks around the A-post.
3. Press downward on the right part ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.