

## Manual, Assembly instruction: Brodit 805294

Left mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Pull out the rubber sealant slightly on the A-post.
2. Press the angled edge on the left part of the ProClip into the gap and hook it around the A-post.
3. Press the right part of the ProClip forward so the angled edge hooks around the A-post. Press on top of the ProClip so the angled edge hooks properly in place.
4. The ProClip is in place.