


Manual, Assembly instruction: Brodit 805304

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap on top of the dashboard, to widen the gap between the dashboard and the panel surrounding the air vent.

2. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.

3. Press the upper part of the ProClip forward so the curved edge hooks into the gap between the gap openers. Press the upper edge all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.