

Manual, Assembly instruction: Brodit 805308

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Remove the adhesive tape cover on the ProClip.
2. Press the lower angled edge under the frame surrounding the air vent.
3. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.