

Manual, Assembly instruction: Brodit 805332

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Pull out the rubber sealent on the A-post slightly.

2. Press the angled edge on the ProClip into the gap and hook around the A-post.

3. Press the upper part of the ProClip forward/upward so the angled edge hooks around the A-post. Press down on top of the ProClip so the angled edge hooks properly in place.

4. The ProClip is in place.