

Manual, Assembly instruction: Brodit 805336

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Tilt the vent louvers to a flat position. Peel off the adhesive tape cover on the ProClip. Insert the lower part of the ProClip into the lower edge of the air vent and hook the angled edge on the lower part of the ProClip behind the frame surrounding the air vent.

2. Press firmly downwards on the top of the ProClip so the ProClip flexes downward. Hook the angled edge on the upper part of the ProClip into the gap between the air vent and the surrounding frame.

3. Press upward on the upper part of the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches.

4. The ProClip is in place.