

Manual, Assembly instruction: Brodit 805344

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.

2. Press the "S" shaped edge on the lower part of the ProClip into the gap between the upper and the lower sections of the dashboard. Press in on the lower edge of the ProClip, in the same time tip the ProClip upward to ensure the lower edge goes into the gap and behind the lower dashboard section.

3. Pull the ProClip upward and hook the upper angled edge into the gap next to the gap opener. Press down on the top of the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches. Pull out the gap opener.

4. The ProClip is in place.