

Manual, Assembly instruction: Brodit 805347

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Pull/flip the rubber sealant open on the A-post.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post panel edge.
3. Press the ProClip forward/leftward so the upper edge hooks around the A-post panel by the windshield. Press until you see/hear/feel it hook into place.
4. The ProClip is in place.