

Manual, Assembly instruction: Brodit 805357

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE! It is very important to place the ProClip exactly in the position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber strip on the A-post slightly so you can locate the two notches on the A-post.

2. Place the lower part of the ProClip between the notches on the A-post. Press the angled edge on the lower part of the ProClip into the gap between the rubber strip and the A-post and hook it around the A-post.

3. Press the ProClip forward/upward so the angled upper edge hooks around the A-post. Press down on top of the ProClip so the angled edge hooks into place properly.

4. The ProClip is in place.