

Manual, Assembly instruction: Brodit 805363

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. 1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the upper part of the ProClip into the upper part of the air vent. Press the edge upward so the adhesive tape attaches.

2. Press the lower part of the ProClip upward/forward and place the lower edge in the lower part of the air vent. Press the edge downward so the adhesive tape attaches.

3. The ProClip is in place.

4. The ProClip is in place.