

Manual, Assembly instruction: Brodit 805415

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the long lower part of the ProClip into the gap between the panel surrounding the air vent and the dashboard.

2. Hook the upper edge of the ProClip into the lower part of the air vent. Press down on top of the ProClip so the adhesive tape attaches.

3. The ProClip is in place.

4. The ProClip is in place.