

Manual, Assembly instruction: Brodit 805446

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the enclosed gap opener into the upper part of the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Press the angled top edge of the ProClip into the gap next to the gap opener. Press the ProClip downward so the angled edge goes all the way into the gap. Remove the gap opener.

2. Press the gap opener into lower part of the gap between the frame surrounding the air vent and the dashboard. Pull the lower part of the ProClip downward and hook the angled edge into the gap between the gap opener. Remove the gap opener.

3. The ProClip is in place.

4. The ProClip is in place.