

Manual, Assembly instruction: Brodit 805463

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent, to widen the gap. Place the angled edge on the lower part of the ProClip by the gap next to the gap opener. Keep the lower edge in that position, in the same time pull the upper part toward you and press the center part forward so the ProClip flexes and the angled lower edge is pointing into the gap.

2. Press the angled edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the dashboard and the frame surrounding the air vent. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.