

Manual, Assembly instruction: Brodit 805501

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the grooved edge on the upper part of the ProClip under the upper edge of the air vent.
2. Press the lower part of the ProClip upward/forward.
3. Hook the grooved edge on the lower part of the ProClip over the lower edge of the air vent.
4. The ProClip is in place.