

Manual, Assembly instruction: Brodit 805524

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Pull out the rubber sealant on the A-post slightly. Locate the small notch on the A-post.
2. Press the angled edge of the ProClip into the gap below the notch.
3. Press the ProClip forward and hook the angled edge over the A-post. Press down on top of the ProClip so the angled edge hooks properly in place.
4. The ProClip is in place.