

Manual, Assembly instruction: Brodit 805532

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.
2. Press a corner of the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard. Then press all of the angled lower edge into the gap.
3. Pull the ProClip upward and hook the angled upper edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.