

Manual, Assembly instruction: Brodit 805534

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the air vent and the surrounding frame.

2. Press the upper part of the ProClip upward/forward so the angled lower edge hooks behind the panel surrounding the air vent.

3. Press the angled upper edge downward and forward. Press the thin upper edge into the gap between the air vent and the surrounding frame.

4. ProClip ist montiert.