

Manual, Assembly instruction: Brodit 805549

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

2. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Pull the upper part of the ProClip upward and hook the angled edge into the gap next to the gap opener. Press downward on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

3. Press the edges of the ProClip toward the frame surrounding the air vent, on both sides at the same time, so the edges go all the way into the gaps and the adhesive tapes attach properly.

4. The ProClip is in place.