

Manual, Assembly instruction: Brodit 805582

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the grooved upper edge of the ProClip under the frame surrounding the air vent.
2. Press the ProClip upward/forward.
3. Press the lower part of the ProClip forward. Hook the grooved lower edge over the frame surrounding the air vent.
4. The ProClip is in place.