

Manual, Assembly instruction: Brodit 805601

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Pull out the rubber sealent on the A-post slightly. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
2. Press the ProClip upward/forward so the angled upper edge hooks around the A-post.
3. Press down on top of the ProClip so it hooks into place properly.
4. The ProClip is in place.