

Manual, Assembly instruction: Brodit 805651

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the trim.
2. Press the upper part of the ProClip downward/forward and hook the angled upper edge into the gap between the frame surrounding the air vent and the dashboard.
3. Press the upper edge all the way into the gap.
4. The ProClip is in place.