

Manual, Assembly instruction: Brodit 805655

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener into the gap between the trim and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the upper part of the ProClip forward and hook the angled upper edge over the frame surrounding the air vent. Press down on top of the ProClip so the adhesive tape attaches properly.

4. The ProClip is in place.