

Manual, Assembly instruction: Brodit 805667

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Pull out the rubber sealant on the A-post slightly to widen the gap.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
3. Press the upper part of the ProClip upward/forward so the angled edge hooks around the A-post.
4. The ProClip is in place.