

Manual, Assembly instruction: Brodit 805676

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

- 1.** Pull out the rubber sealant on the A-post slightly to widen the gap. Press the angled edge on the lower part of the ProClip into the gap.
- 2.** Hook the edge around the A-post.
- 3.** Press the upper part of the ProClip upward/forward so the angled edge hooks around the A-post.
- 4.** The ProClip is in place.