

Manual, Assembly instruction: Brodit 805687

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Place the lower edge of the ProClip over the frame surrounding the air vent.
2. Press downward/forward on the upper part of the ProClip and hook the grooved edge under the frame surrounding the air vent.
3. The ProClip is in place
4. The ProClip is in place.