

## Manual, Assembly instruction: Brodit 805720

Left mount



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the trim.
2. Press the upper part of the ProClip downward/forward. Hook the grooved edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
3. Press upward on the upper part of the ProClip so the edge goes all the way into the gap.
4. The ProClip is in place.