

Manual, Assembly instruction: Brodit 805724

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place grooved edge on the lower part of the ProClip over the frame surrounding the air vent.

2. Press the upper part of the ProClip downward/forward. Hook the grooved edge on the upper part of the ProClip under the frame surrounding the air vent.

3. Press the ProClip forward so it is properly in place.

4. The ProClip is in place.