

Manual, Assembly instruction: Brodit 805728

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener

3. The ProClip is in place

4. The ProClip is in place.