

Manual, Assembly instruction: Brodit 805766

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the mount. Insert the upper part of the mount into the gap between the dashboard overhang and the panel.
2. Press forward on the mount until you hear/feel the angled edge hooks into the gap.
3. Press down on the mount so the angled edge hooks under the dashboard trim.
4. The ProClip is in place.