

Manual, Assembly instruction: Brodit 805784

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover. Pull out the rubber sealant on the A-post. Press the lower part of the mount into the gap and hook it behind the A-post.

2. Press the mount forward/upward so the angled upper edge hooks around the A-post.

3. Press on top of the mount so it hooks into place properly.

4. The ProClip is in place.