

Manual, Assembly instruction: Brodit 805815

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached when the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover on the mount. Insert the lower lip of the mount into the gap between the vent and the trim.

2. Press down and forward on the faceplate of the and insert the upper lip into the gap between the vent and the trim. Press upward with your thumb to make sure the upper lip is fully inserted and the tape attaches properly.

3. The ProClip is in place, view from the side.

4. The ProClip is in place.