

Manual, Assembly instruction: Brodit 805818

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Press the upper part of angled mount into the gap between the frame surrounding the air vent and the dashboard.
2. Press the lower angled edge under the frame surrounding the air vent.
3. Press the mount together carefully.
4. The ProClip is in place.