

Manual, Assembly instruction: Brodit 805820

Left mount

1.)



2.)



3.)



4.)



1. Peel off the adhesive tape covers from the mount. Carefully pull the rubber sealant out of the A-pillar where the mount will install. Press the angled edge on the lower part of the mount into the outer gap and hook it around the A-pillar.

2. Flex the mount upward and forward, so the upper angled edge hooks around the A-pillar by the windshield.

3. Press down on top of the mount so the upper angled edge hooks around the A-pillar securely.

4. The proclip is in place.