

Manual, Assembly instruction: Brodit 805834

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.

2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener. Press on the ProClip so the angled edges go all the way into the gaps.

4. The ProClip is in place. .