

Manual, Assembly instruction: Brodit 805843

Left mount



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip.
2. Press the lower angled edge under the frame surrounding the dashboard.
3. Hook the angled edge on the upper part of the ProClip under the frame surrounding the air vent.
4. The ProClip is in place.