

Manual, Assembly instruction: Brodit 805856

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Make sure the air vent is open, with the flaps positioned for straight air flow. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Place the right edge of the ProClip against the inner right edge of the air vent.

2. Press the left side of the ProClip rightward, flexing it.

3. Place the left side of the ProClip against the left inside of the air vent.

4. The ProClip is in place.