

Manual, Assembly instruction: Brodit 805859

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Insert the thin end of the enclosed gap openers into the gap around the air vent.
2. Insert the lower angled edge of the ProClip into the lower seam under the vent.
3. Using your thumb and fingers, flex the ProClip upward and insert the upper angled edge of the ProClip into the seam between the lower inside of the vent and the frame around the vent.
4. The ProClip is in place.